

- (1) Remove indicator stalk.
- (2) Remove steering wheel centre boss etc. to gain access to large nut.
- (3) Loosen large nut but replace a few turns to protect thread (see drawing).
- (4) Place bolts through holes from reverse side of steering wheel via indicator stalk hole along with washers.
- (5) Fit bar opposite to bow.
- (6) Place with washers and nuts, and then tighten evenly though it is quite hard work.

- ① Metal Bar (slight bow)
- ② Steering Wheel
- ③ Steering Console
- ④ Bolts
- ⑤ Nuts
- ⑥ Woodruff Key
- ⑦ Steering Wheel Nut

